


AB VERIFIER VERSION 2.0 - WHAT NEW?

- **MDI mode (NEW):** This “Multi-Document-Interface” feature allows you to open and work on many plots without having to run multiple instances of the program.
- **Ability to do double AB (NEW):** Most of the pools nowadays have many features that make it hard to measure the pool and obstructions using just single AB. This version of the program allows you to do two separate plots AB (primary plot) and XY (secondary plot), provided that you can give the relationship between the first stake and the second stake (which are the distance between A to X; A to Y; B to X and B to Y).

See below for the illustration.





- **Rotation, Pan and Zoom (FIXED AND ENHANCE):** the first version of this program limited you to rotate the pool from 0 to 90 degree; moreover, if you rotate the pool over 45 degree, the pan and zoom all mode don't work properly. With this version, you can rotate the plot in any degrees and the pan/zoom all will still work properly.

- **More plot information can be entered (ENHANCED):** This version allows you to enter more information for the plot such as the pool address, measuring company,... this is good for the installer to keep track of the plot. You can even set default measuring company information so that this info will be populated with every new plot.


The screenshot shows a software window titled 'Plot Info' with two tabs: 'Primary Plot' and 'Secondary Plot'. The 'Primary Plot' tab is active. The form contains the following fields:

Job Name:	WALKER		
Pool Address:	1234 SOME STREET, MISSISSAUGA, ON		
Dealer:	CONSTRUCTION DISTRIBUTION		
Contact:	MARINA		
Address:	4630 DUFFERIN ST. UNIT 8A		
City:	DOWNSVIEW		
Province:	ONTARIO	Postal Code:	M3H 5S4
Phone:	(416) 665-8006	Fax:	(416) 665-7400
Email:			
Measured By:	TAYLORD SHORE		
Contact:	CHRIS	Phone:	416-xxx-xxxx
Email:	chris@taylorshore.com		


- **What You See Is What You Get - WYSIWYG (NEW):** The program was designed to make it easier to manipulate the plot by allowing you to select, drag the points/drawing entities directly on the screen. So you can select the step points, right-click and convert to the step series to exclude those points from the pool plot to get the proper size of the pool. See below:




- **Perimeter dimension (NEW):** beside the enhanced linear dimension, you can now get the length along the perimeter from one point to another. This is very helpful when you need to know the length of the waterfall or the length where you need to do perimeter padding. Please note that the start point and the end point must be on the same series.



- **Line/Rectangle/Circle (NEW):** You can now draw basic shapes to the plot. This is helpful for the installer to show obstruction, skimmer, diving board...
- **Text/Leader (NEW):** You can also insert text and leader directly in the plot (see below)



- **Grid (NEW):** This version of the program allows you to insert a set of grid lines directly onto the plot. This is very helpful if you want to know approximately number of anchors



The program even provides you a strap calculation tool to help you guess the number of anchors easier.

Strap Calculator

☐ This is a shaped pool (rectangle; grecian; square L ...)

☒ This is a form fit pool (kidney; lagoon; round ...)

Number of main straps:

 Number of steps:

 Number of cut corners:

 Number of small cuts out (slide legs; hand rails ...):

 Number of waterfall cut outs:


 Number of straps that fall into waterfall area:

 Plus/Subtract number of straps:


 Approximately total number of straps (anchors):

Close

- **Printing (ENHANCED):** Now you can select what you want to print (everything or date or plot only), which entities you want to print (dimension, grid, text...) and where you want to print (the whole plot or a portion of the plot only).



Also, the plot is now have title block which make the drawing looks more professional.



- **Other new or enhanced features:** last but not least, beside the previous features, this version of the program also includes some miscellaneous features. For example, you can copy and paste from already entered plot in Microsoft Excel to the grid; notify you with selected sound when an invalid point entered; you can now enter the plot using inches only; what you see on screen is what you get when you export the plot to AutoCAD application (Coverttech version only); printing AB data was organized to save time and paper; you can edit the dealer database directly in the Preferences box (Customer version only); This program now can work with Windows Vista 32/64 bit and Windows 7 32/64 bit (Customer version only).